



MAXIM
DEFENSE®

PDX™ + MDX

OWNER'S MANUAL



Maxim Defense Industries, LLC was born with the mission of being a 21st century defense development company striving to give the military and law enforcement the next generation of tools and equipment that exceed in today's extreme environments.

Our mission is focused on the Special Operation Forces community and developing products that are purpose designed and duty built to meet or exceed demanding challenges they face in this dangerous world.

Our development efforts are focused on servicing this community, but we are also committed to our commercial clients and customers, for without their support we could not achieve our mission of helping those that are down range and in harm's way.

At Maxim Defense we are dedicated to the design and production of only the highest grade in performance firearms and to protect you, who protect us and our liberties selflessly every day.

Michael G. Windfeldt

*President & CEO
Maxim Defense Industries LLC*

CONTENTS

DESCRIPTION, DEFINITIONS, AND NOMENCLATURE	6
UNLOADING/CLEARING	8
LOADING	10
FIRING	12
RELOADING	13
SPECIFIC PARTS DETAILED DESCRIPTION	14
DISASSEMBLY	18
ASSEMBLY	21
FUNCTIONS CHECK	24
CLEANING PROCEDURES	25
INSPECTION OF COMMON PARTS	27
PREVENTATIVE MAINTENANCE	28
LUBRICATION	28
SPECIAL CIRCUMSTANCES AND CONDITIONS	29
WARRANTY, SERVICE AND TECHNICAL REFERENCES	31

4 FIREARM SAFETY RULES

1. Treat every weapon as if it were loaded.
2. Never point a weapon at anything you do not intend to shoot.
3. Keep your finger straight and off the trigger until you intend to fire.
4. Keep the safety on until you are ready to fire.

ADDITIONAL SAFETY CONSIDERATIONS


The safety selector should remain on SAFE until you are ready to FIRE, then placed back on SAFE.

WARNING: It is your responsibility to reference and obey all federal, state and local laws and regulations on the possession, carriage, and discharge of firearms. Law enforcement and military consumers are responsible for referencing and obeying the policies of their respective agencies that apply to the carry and use of this rifle.

Disclaimer: Maxim Defense assumes no liability or, responsibility for the misuse, criminal use, nefarious activity with or, negligent use of this firearm. Maxim Defense encourages the user to seek consistent professional firearms training.

DESCRIPTION, DEFINITIONS AND NOMENCLATURE

- | | | | |
|-------------------------|---------------------------|------------------------------|---------------------------------|
| 1. Stock/Brace | 7. Handguard | 13. Grip | 19. Forward hand stop |
| 2. Forward assist | 8. QD sling mount | 14. Trigger | 20. Ambi-magazine catch |
| 3. Ambi-charging handle | 9. M-slot mounting system | 15. Magazine release | 21. Bolt catch/release |
| 4. Upper receiver | 10. HATEBRAKE™ | 16. Magazine well | 22. Ambi-safety selector |
| 5. Ejection port door | 11. Rear take down pin | 17. Front pivot pin | 23. Stock/Pistol release button |
| 6. Optic/accessory rail | 12. Ambi-safety selector | 18. Handguard retention bolt | 24. QD sling mount |



FEATURES

- 7075-T6 billet upper and lower receiver 6061 extruded free floated handguard Maxim Defense stock/pistol brace system
- M-Slot accessory attachment points nitride coated military grade barrels
- Barrel lengths of 5.5", 8.5", 10.3"
- HATEBRAKE™ muzzle booster device
- Forward hand stop
- Geissele®/ALG combat enhanced trigger system
- Radian ambidextrous selector switch
- Radian ambidextrous changing handle
- Bilateral magazine release
- Offset QD sling mounts
- Non-Proprietary common armorer tools
- Available as a Pistol or SBR



UNLOADING/CLEARING

OBEY THE 4 FIREARMS SAFETY RULES AT ALL TIMES (Refer to Page 5 where this is in detail)

WARNING: Always stay clear from the ejection port when clearing the firearm.

1. With the Internal hammer cocked, ensure that the manual Safety Selector is rotated to the "SAFE" position. If the manual Safety Selector switch will not rotate, the internal Hammer is in the De-Cocked position, continue to the next step.



2. **REMOVE THE SOURCE OF AMMUNITION:** Remove the Magazine from the Magazine Well by depressing the Magazine Release Button. The Magazine should fall freely from the Magazine Well. If no Magazine is present in the Magazine Well, continue to the next step.



3. Pull back on the Charging Handle from the Upper Receiver. This will pull the Bolt back and expose the Chamber. While holding the Charging Handle fully to the rear, depress the bottom of the Bolt Catch, then slowly release the Charging Handle until the Bolt Catch retains the Bolt to the rear.

Push the Charging Handle back into the Upper Receiver until the Charging Handle Latch clicks into place on the Upper Receiver.

4. Visually and Physically inspect the Chamber, Magazine Well, and Bolt Face to ensure that NO Ammunition is present in the firearm.



LOADING

OBEY THE 4 FIREARMS SAFETY RULES AT ALL TIMES (Refer to Page 5 where this is in detail)

WARNING: Ensure that the Ammunition is Caliber Compliant with the Firearm. Failure to do so could cause physical harm to the shooter and damage to the firearm.

LOADING THE FIREARM WITH THE BOLT ASSEMBLY TO THE REAR

1. With the Safety Selector Switch in the "SAFE" position, insert a Loaded Magazine into the Magazine Well. Push inward until the Magazine Catch engages and holds the Magazine.
2. Give a slight pull to the Magazine to ensure that the Magazine is fully seated. If the Magazine pulls out, tap the bottom of the Magazine to ensure Magazines retention.
3. Depress the upper portion of the Bolt Catch/ Release allowing the Bolt Assembly to go forward and Chamber a round of Ammunition. **Your firearm is now loaded.**



Best Practices: Tap the Forward Assist to ensure that the Bolt is fully seated forward and close the Dust Cover.

LOADING THE FIREARM WITH THE BOLT ASSEMBLY CLOSED



1. With the Safety Selector Switch in the "SAFE" position, insert a Loaded Magazine into the magazine well and push inward until the Magazine Catch engages and holds the magazine.
2. Give a slight pull to the magazine to ensure that the magazine well is fully seated. If the magazine pulls out slightly, tap the bottom of the magazine to ensure magazine retention.



3. Pull back Charging Handle completely to the rear and release, allowing the Bolt Assembly to go forward and chamber a round of ammunition. **Your firearm is now loaded.**

Best Practices: Tap the Forward Assist to ensure that the Bolt is fully seated forward and close the Dust Cover.

FIRING

OBEY THE 4 FIREARMS SAFETY RULES AT ALL TIMES (Refer to Page 5 where this is in detail)

1. Align the Sight System with the Target.
2. Rotate the Selector Switch from “SAFE” to “FIRE”.
3. Place your finger on the Trigger and apply steady pressure on the Trigger to the rear until the firearm discharges a round of ammunition.

SEMI-AUTOMATIC The firearm will discharge only one round, cycle on its own and reload a new round of Ammunition into the Chamber completing a Cycle of Operation. Once the cycle is complete, release the pressure from the Trigger allowing the Trigger to travel forward on its own until the Trigger Resets. The firearm is ready to fire again.

SELECT-FIRE* The firearm will discharge rounds of Ammunition while the Trigger is held. The Firearm will stop shooting when the Trigger is released or the firearm runs out of ammunition, whichever occurs first.

4. When done firing, remove your finger from the Trigger and move the Selector Switch from “FIRE” to “SAFE”.
5. When Firing and the Ammunition from the Magazine is depleted, the Follower from the magazine should engage the Bolt Catch thus causing the Bolt Assembly to be held to the rear exposing an empty Chamber.

* All NFA Rules apply. Maxim Defense only manufactures and sells Select Fire firearms according to BATFE Rules.

RELOADING

OBEY THE 4 FIREARMS SAFETY RULES AT ALL TIMES (Refer to Page 5 where this is in detail)

1. Place the firearm on Safe by rotating the Safety Selector Switch to “SAFE” from “Fire”.
2. Remove the Magazine by depressing the Magazine Release Button and removing the empty Magazine from the Magazine Well. The Magazine should fall freely on its own.
3. Insert a loaded Magazine of Caliber Specific Ammunition into the Magazine Well and push inward until the Magazine Catch engages and holds the Magazine.
4. Give a slight pull to the Magazine to ensure that the Magazine Well is fully seated. If the Magazine pulls out slightly, tap the bottom of the Magazine to ensure Magazine retention.
5. Depress the upper portion of the Bolt Catch/ Release allowing the Bolt Assembly to go forward and chamber a round of Ammunition. **Your firearm is now loaded.**

Best Practices: Tap the Forward Assist to ensure that the Bolt is fully seated forward and close the Dust Cover.

SPECIFIC PARTS DETAILED DESCRIPTION



MAGAZINE

A semi-automatic firearm can only run as well as the Magazine used. Maxim Defense only utilizes the best Magazines available from the top manufactures in the industry and has provided one with this rifle. Load Ammunition into the Magazine by pressing down on the cartridge and sliding the round of Ammunition to the rear of the Magazine ensuring that the round is held by the Feed Lips of the Magazine.

WARNING: DO NOT overload the Magazine more than what the maximum capacity of individual rounds of Ammunition calls for. Your Firearm may malfunction. **DO NOT** apply lubrication to the Magazine or Ammunition.



CHARGING HANDLE

To manually cycle the action of the firearm, grasp the Charging Handle and pull it fully to the rear of the firearm. When performing Unloading or Clearing procedures to the firearm, the Charging Handle may be slowly eased or "Rode" forward on an empty chamber. This is done by slowly easing the Charging Handle to the forward position and re-latching the Charging Handle to the Upper Receiver. However, when loading a round of Ammunition into the Chamber, the Charging Handle should never be "Rode" forward. Instead the Charging Handle should be pulled completely to the rear and released allowing the Recoil Spring to thrust the Bolt Carrier Group forward chambering a round of Ammunition.



BOLT CATCH

The Bolt Catch is engaged by the Magazine Follower on an empty fully inserted Magazine. When the Magazine Follower is positioned at the top of the Magazine, a tab on the rear of the Magazine Follower pushes up on the Bolt Catch causing the Bolt Assembly to be "Caught" by the Bolt Catch.

To lock the Bolt Assembly to the rear and expose the Chamber without the use of a Magazine:

Pull back on the Charging Handle from the Upper Receiver. This will pull the Bolt back and expose the Chamber. While holding the Charging Handle fully to the rear, depress the bottom of the Bolt Catch, then slowly release the Charging Handle until the Bolt Catch retains the Bolt to the rear. Push Charging Handle back into the Upper Receiver until the Charging Handle Latch clicks into place on the Upper Receiver.



To Release the Bolt using the Bolt Catch/Release:

With the Bolt Assembly held to the rear by the Bolt Catch, to release the Bolt Carrier Assembly simply press the top of the Bolt Catch. The Bolt Catch will then release the Bolt Carrier Assembly from the spring pressure of the Action/ Recoil Spring allowing the Bolt to lock into Battery of the Chamber.

COLLAPSABLE SCW & CQB PISTOL BRACE OR STOCK




Maxim Defense stock and pistol braces are designed for rapidly deployment by simply grasping the stock or pistol brace and pulling back towards the rear of the firearm. The stock or pistol brace will fully extend to the furthest extension and lock into place. The stock or pistol brace may be shortened to a desired length of pull. To adjust the length or collapse the stock or pistol brace push in the stock/pistol brace release button located behind the pistol grip on the left side of the firearm.

To remove stock/pistol brace from the firearm:

Simultaneously press in both the stock/pistol brace release button and the stock/pistol brace clamp lock. Both of which are located behind the pistol grip and need to be pressed inward and held together, then slide the stock/pistol brace out of the pistol brace housing.

To install stock/pistol brace from the firearm:

While simultaneously pressing together the stock/pistol brace release button and the stock/pistol brace clamp lock, insert the stock rods into the stock/pistol brace housing. Set at desired length of pull.



VERTICAL FOREGRIP OR HANDSTOP INSTALLATION

Maxim Defense firearms include an installed hand stop as an indexing device for finger placement. In order to prevent the possibility of injury, **NO** part of your hand should be placed in front of the front hand stop.

DISASSEMBLY

NOTE: The Firearms must be clear of all ammunition before inspecting, cleaning, disassembly, transporting or, storing to be considered safe. Refer to Clearing Procedures on page 8-9.


NOTE: The following procedure is **ONLY** for the PDX with SCW stocks/pistol braces.

1. Verify that the firearm is clear of any ammunition in the chamber and magazine well.
2. Ensure that the stock/pistol brace is fully extended to the rear, so the stock/pistol brace rods are not covering up the rear takedown pin.
3. Push both the takedown and pivot pin from the left to the right until you feel a positive stop.
4. The upper and lower receiver assemblies may now be simultaneously pulled apart while slightly lifting. The buffer assembly should remain with the lower and recoil spring will extend out from the buffer tube. It should be noted that there is not a buffer retainer detent or underlying buffer retainer spring in.
5. Slightly pull back on the charging handle to expose the bolt carrier from the upper receiver assembly. Remove the bolt carrier only.
6. Gently pull back on the charging handle until you feel slight resistance. Remove the charging handle from the upper receiver by maneuvering the charging handle ears through the channel slot grooves in the upper receiver.
7. Remove the buffer and spring. Your Maxim Defense firearm is now disassembled into three main assemblies: Upper Receiver, Lower Receiver, Bolt Carrier Group.



NOTE: The following procedure is **ONLY** for the MDX with CQB stocks/pistol braces or carbine stocks/pistol braces.

1. Verify that the firearm is clear of any ammunition in the chamber and magazine well.
2. Ensure that the stock/pistol brace is fully extended to the rear, so the stock/pistol brace rods are not covering up the rear takedown pin. Push the rear takedown pin from the left to the right until you feel a positive stop.
3. The upper and lower receiver assemblies will now pivot away from each other while still joined by the front pivot pin. The front pivot pin may also be pushed from the left to the right until you feel a positive stop. This will allow the upper and lower receiver assemblies to be separated from one another.
4. Slightly pull back on the charging handle to expose the bolt carrier from the upper receiver assembly.
5. Remove the bolt carrier and buffer system. Your Maxim Defense firearm is now disassembled into three main assemblies: Upper Receiver, Lower Receiver, Bolt Carrier Group.




BOLT CARRIER DISASSEMBLY

1. Remove the firing pin retaining pin. (1)
2. Remove the firing pin. (2)
3. Ensure that the bolt is fully inserted into the bolt carrier.
4. Rotate the cam pin $\frac{1}{4}$ turn in either direction and pull out of the bolt carrier. (3)
5. Remove the bolt from the bolt carrier by pulling on the bolt while twisting. (4)

Your bolt carrier group is now "Field Stripped".

To remove the extractor for replacement or repair from the bolt:

1. Apply pressure with your fingers to compress the extractor.
2. Push out the extractor pin from either side.
3. Life the extractor from the bolt.



ASSEMBLY


BOLT AND BOLT CARRIER ASSEMBLY

Extractor Reassembly to Bolt.

1. Press the extractor onto the bolt where the cut out is for it.
2. Apply finger pressure by pressing down to index the extractor pin hole on the side of the bolt. Insert the extractor pin from either side of the bolt. Ensure that the extractor pin is set equally sub-flush into place.

BOLT CARRIER ASSEMBLY

1. Press the tail end of the bolt into the bolt carrier. When you feel slight resistance, rotate either direction and apply slight pressure to seat the bolt into the bolt carrier.
2. Ensure the bolt is fully seated into the bolt carrier and index the cam pin hole. The correct orientation will have the extractor portion of the bolt in the upper right corner of the bolt face. Insert the cam pin so it passes the bolt carrier gas key.
3. Rotate the cam pin $\frac{1}{4}$ turn either direction.
4. Insert the firing pin so it sits flush into the back of the bolt carrier.
5. Insert the firing pin retaining pin from the left so it sits flush into the bolt carrier.



ASSEMBLY OF THE UPPER RECEIVER

NOTE: The following procedure is ONLY for the PDX with SCW stocks/pistol braces. There are no buffer retainer detents on this series.

1. Insert the charging handle into the rear of the upper receiver maneuvering the charging handle ears into the groove track so the handle sits in its position in the top of the inside of the upper receiver. Leave the charging handle protrude from the back of the upper receiver by approximately three inches (3”).
2. Ensure that the bolt is fully extended from the bolt carrier, then insert the bolt carrier group into the upper receiver so the bolt carrier key rests into the charging handle.
3. Insert the buffer behind the bolt carrier group and press forward until the bolt sets into battery of the chamber and the charging handle latch locks to the upper receiver and the Maxim Defense shortened buffer.
4. Once the receivers are matched together, press the front pivot pin and the rear take down pin flush into the firearm locking the receivers together.
5. Perform a function check. (Page 24).



NOTE: The following procedure is ONLY for the MDX with CQB stocks/pistol braces or carbine stocks/pistol braces.

1. Insert the charging handle into the rear of the upper receiver maneuvering the charging handle ears into the groove track so the handle sits in its position in the top of the inside of the upper receiver. Leave the charging handle protrude from the back of the upper receiver by approximately three inches (3”).
2. Ensure that the bolt is fully extended from the bolt carrier, then insert the bolt carrier group into the upper receiver. Slide the bolt carrier group and charging handle all the way forward until it is flush in the upper receiver assembly and the charging handle latch locks into place.
3. Ensure that the buffer is inserted into the extension tube and being retained by the buffer retainer detent.
4. Align the upper receiver assembly over the lower receiver assembly.
5. Once the receivers are matched together, press the front pivot pin and the rear take down pin flush into the firearm locking the receivers together.
6. Perform a function check. (Page 24).



FUNCTIONS CHECK

A proper Function Check should be performed every time your firearm has been taken apart and reassembled. The purpose of the Functions Check is to ensure that all of the components are correctly installed, and the Firearm will function correctly.

WARNING: A Proper Functions Check includes the Insertion of an empty Magazine and also Dry Firing the Firearm. You MUST ENSURE that the Firearm and Magazine are clear of ALL AMMUNITION

1. Check and Verify that the Firearm is unloaded by locking the Bolt Carrier Group back with the Bolt Catch as described on page 13. Check and Verify that you have an unloaded Magazine with **NO** Ammunition.
2. Start with your Cleared Firearm, the Firearm Selector Switch rotated to the Safe position, the Bolt forward in the Closed position and the Dust Cover Closed.
3. Insert the **EMPTY** Magazine into the Magazine Well until the Magazine is retained by the Magazine Catch. Tap the bottom of the Magazine then Tug the Magazine to ensure that it is properly seated.
4. Pull back on the Charging Handle. The Bolt Catch Will engage the Empty Magazine Follower and retain the Bolt Carrier Group and, the Dust Cover will spring open. Push the Charging Handle Forward and Lock into the forward position.
5. While Keep the Firearm pointed in a safe direction forward, push the Magazine Release Button and let the Magazine fall freely into your hand. Do not pull or assist the Magazine.

6. Pull back on the Charging Handle, watch the Bolt Catch Drop back into the rest position.
7. Release the Charging Handle allowing the Recoil Spring to freely push the Bolt Carrier Group forward and lock into battery with the Chamber. Do not release the Bolt Carrier Forward by depressing the Bolt Catch. Do not "Ride" the Charging Handle forward for this will not allow the Bolt Carrier Group to fully seat into Battery.
8. With the Unloaded Firearm pointed in a Safe Direction and the Selector Switch on Safe, press the Trigger. The Trigger should not move or release the Hammer.
9. With the Unloaded Firearm pointed in a Safe Direction rotate the Selector Switch to Fire, Press the Trigger. You should hear the Hammer fall.
10. While still Holding the Trigger to the rear and not letting go, pull back on the Charging Handle to cock the Hammer. Release the Charging Handle allowing the Recoil Spring to freely push the Bolt Carrier Group forward and lock into Battery.
11. Slowly release the Trigger until you feel and hear an audible Click. Do not release the Trigger. This sound came from the internal Hammer that was held by the Disconnecter being released and engaging the front of the Trigger causing the Sear to engage.
12. Slowly press the Trigger a second time allowing the Hammer to again fall forward.
13. Release the Trigger and Attempt to rotate the Selector Switch to Safe - it should not move.
14. You may now either Store the Firearm or Load as shown on page 10.

CLEANING, PREVENTATIVE MAINTENANCE AND LUBRICATION

With a variety of operational conditions and the varied pressures of ammunition, your firearm should be cleaned and inspected after each use. And to maintain optimal performance, a Preventative Maintenance Program must be established and followed.

Maxim Defense Industries only recommend Lubrication and Cleaning Solvents that are designed for firearms to be used.

WARNING: Always Unload and CLEAR your firearm before maintenance and cleaning as shown on page 8. DO NOT mix parts from one firearm with parts from another firearm. Parts are not interchangeable unless specifically designated as such. DO NOT mix lubricants on the same firearm. The User is responsible for following all instruction for the safe use of Lubricants and Solvents.

NOTE: The term "CLP", "Cleaning Solvents" and Lubricant" in this manual are used interchangeably and are to be interpreted to mean that CLP, LSA LAW can be utilized as applicable. The Firearm must be thoroughly cleaned during the change from one lubricant to another using a dry cleaning Solvent (SD). **DO NOT** mix lubricants on the same firearm.

RECOMMENDED TOOLS:

- Cleaning Solvent
- Grease, Molly based
- Bore Cleaner
- Cleaning Rod Caliber Specific to your Firearm (.22/5.56 - .30/7.62)
- Cleaning Rod Jag for Patches
- Bore Brush Caliber Specific to your Firearm (.22/5.56 - .30/7.62)
- Chamber Bush/ Mop Caliber Specific to your Firearm (.22/5.56 - .30/7.62)
- Nylon Bristle Brush
- Small Arms Wiping Rags/Pipe Cleaner

CLEANING THE FIREARM

1. Ensure that your firearm is clear of any ammunition as shown on page 6. **DO NOT** allow any ammunition in the cleaning area.
2. Separate your Upper and Lower Receiver Assemblies as shown on page 14.
3. Remove the Bolt Carrier Group and Charging handles as shown on page 15.
4. Disassemble the Bolt Carrier Group as shown on page 16.

CLEANING THE BOLT CARRIER GROUP

1. Using a Carbon Solvent and the Nylon Bristle Brush, clean all carbon fouling from the Bolt Locking Lugs and the Bolt Face.
2. Remove the carbon fouling from the rear of Bolt behind the Gas Rings.
3. Clean the Extractor paying particular attention to the Extractor Claw. Clean the Extractor Slot in the Bolt.
4. Using a pipe cleaner, clean the Firing Pin Channel in the Bolt.
5. Remove any carbon from the Bolt Carrier and wipe down.
6. Wipe away the carbon build up on the Firing Pin paying close attention under the collar.

CLEANING THE BARREL

Either utilizing a Free Rotating Cleaning Rod or a Pull Through System will allow the bore brush and swabs to follow the lands and grooves of your bore.

Ensure that you start from the Breach and end at the front of the barrel. Never change directions mid bore, your Jig, Brush or Swab will get stuck.

1. Coat a patch with bore cleaner. Run a wet patch, replace with another wet patch. Do this at least 5 times and then let sit allowing the cleaner to work for at least 5 minutes.
2. Run one more wet patch to remove fouling.
3. Using a Bronze Brush make ten strokes. Reapply Solvent as needed. Do not dip the brush into the solvent bottle but use a small container to as not contaminate supply.
4. Run Dry patches through Barrel to remove fouling and solvent until the patches come out clean.
5. Wet a patch with a Copper Solvent, run through the bore and let set for a few minutes. Follow with another Copper Solvent wet patch, wait, repeat until the patches have no blue stains on the patches. A cleaning jag may be used for this process. This is important for the copper fouls the grooves in the bore.
6. Before introducing a new solvent, ensure that the bore is dry of the solvent that was previously used.
7. Finish with a wet patch of CLP.

EJECTOR CLEANING PROCEDURES

1. Place a few drops of CLP on the Ejector.
2. Press the ejector in using a spent shell casing or inert dummy round. **DO NOT USE A LIVE ROUND TO PERFORM THIS PROCESS.** Hook the casing under the Extractor and rock back and forth against the ejector. Repeat this process a few times adding CLP until the action of the Ejector is smooth and strong.
3. Dry off excess CLP when process is completed.

CLEANING THE CHAMBER

1. Elevate the Barrel so solvent will not run down the clean Bore.
2. Use a Chamber Brush coated in boar cleaner to clean the chamber.
3. Rotate while plunging the Chamber brush at a minimum five time to remove carbon fouling inside the chamber locking lugs.
4. Clean any residual Carbon with cotton patches, swabs or chamber mop.

RECOIL SPRING AND EXTENSION TUBE

1. Wipe down the Recoil Spring with a dry cloth. Then wipe again with a wet patch of CLP, wipe with a dry cloth one last time. Do not pull the Recoil Spring to extend it.
2. Clean the inside of the extension tube of carbon with a dry cloth patch.

LOWER RECEIVER ASSEMBLY

1. On the Inside of the Lower Receiver Magazine Well, using a dry cloth, wipe areas where carbon fouling is observed. Wipe the Hammer with a cloth patch that has a light amount of CLP, then follow with a dry patch to remove residue. Avoid the inside of the fire control group where the springs are.

The Fire Control Group which consists of the Hammer, Hammer Spring, Hammer Pin, Trigger, Trigger Spring, Trigger Pin, Disconnecter and Disconnecter Spring should only be done by those with an Armorer Certification or Gunsmith.

CLEANING THE MAGAZINE

1. The Magazine is paramount to the function of the firearm. Magazines should be cleaned when the rifle is cleaned and maintained. Remove the Floor Plate, Spring and Follower. Wipe with a dry cloth any residue from the inside and outside of the magazine body.

INSPECTION OF COMMON PARTS

- Charging Handle - This is a one-piece replaceable unit. Inspect the Latch and Spring for damage, inspect the handle body for breaks, bends or excessive wear.
- Upper Receiver Body: Check for cracks or deformities. Depress the Forward Assist and release for proper function.
- Dust Cover Door: should latch shut and spring open.
- Upper Receiver: Check for cracks on bottom lugs that attach to the Lower Receiver.
- Bolt: Check the Bolt face for excessive pitting, look for any cracking or fracturing at the Cam Pin Hole and around Lugs.
- Firing Pin: Check for cracking, fracturing or a sharpened point.
- Bolt Carrier: Check for loosened Screws on the Gas Key.
- Gas Rings: if they are worn they need to be replaced.

PREVENTATIVE MAINTENANCE/PARTS REPLACEMENT SCHEDULE

Maxim Defense Industries have developed innovative designs to maximize reliability with our firearms. However, as with any machine, preventative maintenance is required to maintain the reliability that you depend on. With proper lubrication of your firearm, the use of quality ammunition as recommended and the replacement of common parts that wear down with use such, your Maxim Defense Firearm will always be there for you. At Maxim Defense Industries we are very conservative when it comes to our part replacement schedule for the end user. We recommend on a user level to replace at Three Thousand Rounds (3000) the Gas Rings, Buffer Spring, Extractor and, Extractor Springs. Correct Preventative Maintenance solves issues before they occur.

LUBRICATION

Maxim Defense Industries only recommends the use of Firearm Lubrication that has been designed specifically for the use on Firearms to be used on our firearms. The Type of lubricant used is generally dictated by the environmental conditions that the user find themselves in. The terms CLP, LCA, LSW, Grease and Lubricant are used interchangeable in this manual and are to be interpreted to mean a lubricant to be used as applicable to the conditions and situations that the firearm may be used in.

Lubrication should be applied to moving parts and where two parts contact one another.

- CLP: Cleaner, Lubricant, Protect/ Preserve- Best choice for taking care of firearms for it Cleans, Lubricates and Preserves/ Protects in one step.
- LSA- Lubricant, Semi-Fluid, Automatic Weapons- Strictly a Lubricant.
- LSA-T- Lubricant, Semi-Fluid, Automatic Weapons with Teflon-Strictly a Lubricant.
- LAW- Lubricating Oil, Arctic, Weapons- Environmental conditions that are

sustained below -0°F.

- Grease: Preferably Molybdenum Disulfide compound of Grease, to be used for extreme conditions.
- Light Lube: A film barely visible to the eye.
- Heavy Lube: A film thick enough to spread with your finger.

ONLY USE ENOUGH LUBRICANT SO THAT YOU CAN SEE THE SHEEN ON THE PART BUT NOT SO MUCH THAT IT WILL “RUN” UNDER GRAVITY. THE USE OF GREASE NEEDS TO BE RUBBED INTO THE PART SO THAT IT ONLY LEAVES A SHEEN

KEY LUBRICATING POINTS:

- Bolt Carrier Assembly: Inside Bolt at rear, Gas Rings, Cam Pin, Locking Lugs, Bearing Surfaces of the Bolt Carrier, Ejector area on the Bolt Face, Extractor and Extractor Pin, Charging Handle body.
- Lower Receiver Assembly: Fire Control Springs, Take Down and Pivot Pins along with their Detents, Trigger Sear Surface and Disconnecter Surface.

LUBRICATION SPECIAL CIRCUMSTANCES AND CONDITIONS:

Extreme Cold Weather Climates:

NOTE: Small amounts of CLP on moving parts can freeze and prevent the firearm from firing in extreme cold conditions. Thoroughly remove CLP from the firearm and apply LAW for use in extreme cold weather.

1. Clean and Lubricate the firearm in a warm room with the firearm at room temperature.
2. Apply a light coat of Lubricating Oil for Arctic Weapons (LAW) to Key Lubricating Points.
3. Keep the firearm covered when moving from warm to cold areas in order reduce condensation and / or freezing. Allow firearms to cool gradually if feasible.
4. Keep firearm dry whenever possible. DO NOT lay warm firearm directly on ice or in snow.
5. Condensation will form on firearm when moved from a cold area to a warm area. Firearm should be disassembled and wiped dry several times as it warms to room temperature.
6. Keep ammunition and the insides of magazines wiped dry. Moisture will freeze and possibly cause malfunctions
7. DO NOT lubricate ammunition.

Humid Climates:

1. Perform regular maintenance prior to and after use.
2. Clean and lubricate with CLP more frequently than normal.
3. Inspect all parts of the firearm for corrosion more frequently and more completely than normal maintenance procedures.
4. Remove handprints from the firearm with a dry rag and lubricate the outside surfaces with CLP.
5. Unload and check inside of magazines for corrosion and moisture frequently. Ensure ammunition is dry before reloading magazines.

Desert/Arid Climates

The dry conditions of desert/ arid environment will evaporate light coatings of CLP however, a generous amount of CLP will collect dust and gunk up the rifle. It is imperative that the user perform daily maintenance on their rifle for proper function.

1. Clean inside and functional areas of the firearm every day and after firing in desert conditions. Dust and sand will get into the firearm and magazines and cause malfunctions.
2. In a desert/ arid environment, generous amounts of lubrication should be applied to the internal working surfaces and functional parts of the firearm. Unload and dry ammunition and the inside of magazines daily. DO NOT lubricate magazines.
3. Keep the bolt and ejection door closed, magazine in the magazine well and if possible, a muzzle cap on to keep the sand and dust out of the firearm.

Heavy Rain and Waterborne Operations

1. Ensure that the dust cover is closed.
2. Perform regular maintenance prior to and after use.
3. ALWAYS attempt to keep the firearm dry.
4. ALWAYS drain water from the barrel before firing by pointing downward and shaking as necessary. In a controlled and safe environment, field strip the firearm and dry the bore with a swab and cleaning rod if wet.
5. If water is retained in the barrel from a vacuum, pull the charging handle back just enough to release the pressure seal of the vacuum to drain the water from the barrel. When releasing the Charging Handle there may not be sufficient spring pressure to put the Bolt fully into Battery in the Chamber. Push on the Forward Assist to ensure the Bolt is properly seated, then close the dust cover.

Salt Water Operations

1. Clean sights and optics as soon as possible of saltwater.
2. Wash sights and optics with fresh water source if not able to immediately apply a CLP.
3. Follow the Heavy Rain and Waterborne Operations as previously described.

WARRANTY, SERVICE AND TECHNICAL REFERENCE INFORMATION

For current warranty information, please refer to our website www.maximdefense.com

WARRANTY

Before this firearm left the factory, it was carefully inspected, and test fired for safety and functionality. Maxim Defense Industries, LLC warrants the enclosed firearm to be manufactured free of defects in material. All firearms are assembled with the highest regard. Maxim Defense Industries agrees to correct any defect in the firearm for the original purchaser by repair, replacement or adjustment, at the option of Maxim Defense Industries, LLC. This is a limited lifetime warranty for the original purchaser provided, with the proof of purchase receipt to original purchase date when making a claim.

The firearm was designed to function in its factory configuration. Maxim Defense Industries, LLC maintains the right to void all warranty coverage for this firearm if any part is added, substituted, or modified in any way. Maxim Defense Industries, LLC further maintains the right to void all warranty coverage where firearms that have been disassembled beyond the scope of what is described within the User Manual. This does not apply to normal wear and tear of any parts, and it is the user's responsibility to follow the Preventative Maintenance as described on page 23. No implied warranties of any kind are made herein, and this warranty does not apply to any accessories including optics, illumination, or aiming devices that are added or attached to the firearm.

STORAGE

Never leave any firearm in a manner that will allow visual or physical access to children, minors, or other inexperienced person or, any person who is unauthorized to be in possession of a firearm. Maxim Defense Industries, LLC provides a new mechanical gun lock device with each firearm as a redundancy for safe firearm storage. More than one aspect of responsible storage should be utilized to include storing your firearm unloaded and locked with the provided mechanical device, separate from any ammunition and inside of a lockable storage device.

SILENCERS

Maxim Defense Industries, LLC does not warranty, assume any liability or responsibility for damages incurred, or injury or property damage received from firing a Maxim Defense Industries firearm with a silencer not manufactured by Maxim Defense Industries, LLC. Maxim Defense Industries, LLC retains the right to void all warranty coverage of the firearm if technicians suspect that a silencer was not mounted correctly, to include but not limited to: following the silencer's manufacturer's recommended torque specification for installation, using the proper amount of and proper specific thread locker, checking alignment properly and with the proper tools, installing the silencer with the proper tools, etc. Maxim Defense Industries, LLC firearms should not be fired with silencers that are not manufactured by Maxim Defense Industries, LLC that are further not on the Maxim Defense firearm approved silencer list. This list specifically identifies silencers that are compatible, and whose manufacturers have done the proper engineering to approve their silencers with Maxim Defense firearms (see www.maximdefense.com). Please contact the manufacturer of your suppressor and inquire for compatibility inquiries with any of your firearms.

AMMUNITION

The use of hand loaded, reloaded, remanufactured, imported, low-quality steel cased ammunition or, incorrect caliber will void any warranty in our Firearms. The high pressures that are involved with incorrect ammunition not produced to SAAMI, NATO or CIP specifications can cause death or serious bodily injury. Damage can result from the wrong ammunition, bore obstructions, power overloads or incorrect cartridge components. Maxim Defense Industries only recommends the use of High Quality, Commercially Manufactured, Domestically Produced, new ammunition that meets Sporting Arms and Ammunition Manufactures Institute (SAAMI) or CIP ammunition specifications.

Ensure that the ammunition is in good condition, clean, dry and undamaged prior to use. To ensure our firearms pass the most rugged and demanding firing schedules and provide the highest quality shooting experience, Maxim Defense Industries, LLC researches and tests many of the most commonly available munitions on the market today. The Maxim Defense Industries LLC, line of firearms available in 7.62x39 mm are assembled with an Enhanced Firing Pin. The Enhanced Firing Pin is extended to compensate for known tolerance issues found within some imported steel cased ammunition.

PERSONAL PROTECTION EQUIPMENT AND LEAD EXPOSURE

Discharging Firearms in poorly ventilated areas, cleaning firearms or handling ammunition may result in the exposure to lead and other substances. The use of Personal Protection Equipment such as gloves and eye protection is recommended to mitigate lead exposure. Wash your hands with soap and cold water after the use of firearms and before the consumption of any food or beverage.

Always use Eye and Hearing Protection when shooting or near others who are shooting. Failure to use proper hearing protection will cause permanent hearing damage to include permanent loss of hearing. Failure to use proper eye protection

can result in damage to the eyes including the permanent loss of vision from high velocity flying particles, propellant gasses, ricocheting fragments and other debris.

GENERAL LIABILITY

This is a firearm. Failure to heed any of these warning provided may result in death or serious injury to you or others, as well as severe damage to the firearm and other property. It is the responsibility of the user of this firearm to ensure that they are in compliance with all local Municipal, County, State and, Federal Laws in the region that they are using this firearm. Failure to comply with local ordinances and or State or Federal laws may result in Fines and or Imprisonment. It is the responsibility of the end user to use this firearm in a safe and legal manner.

Maxim Defense Industries is not liable for any misuse, illegal use, unauthorized use of, criminal or negligent discharge, improper or careless handling, corrosion, unauthorized modifications, or other influences beyond Maxim Defense Industries, LLC's direct and immediate control. This limitation of liability applies regardless of whether liability is asserted on the basis of contract, negligence, or strict liability including any failure to warn. Under no circumstances shall Maxim Defense Industries LLC, be liable for incidental or consequential damages, such as but not limited to loss of earnings or profits, commercial loss and loss of use of property.

SHOOTING PRECAUTIONS

Follow the four Firearm Safety Rules at all times.

Never consume alcohol or take drugs when handling firearms. Consult with a Physician if you are taking any medication to ensure that you are fit to handle and discharge a firearm safely.

Always be aware of the location of others around you while using your firearm. Spent cartridge shell casings are very hot and are ejected with enough force where they could cause injury by impact or burn.

When using of a sling, maintain positive control of your firearm and ensure that the safety selector is on safe at all times.

If you experience a failure to fire, always keep the firearm pointed in a safe direction for at least 30 seconds. If a hang fire or a slow ignition were to have occurred, the round will fire within those 30 seconds. If the cartridge still does not fire after 30 seconds, manual cycle the bolt with the charging handle while maintaining safe muzzle management, move the selector switch to SAFE. Examine the primer of the cartridge to see if there is a firing pin indent that is similar to other discharged cases. Separate that cartridge for proper disposal.

CONTACT INFORMATION:

Customer Service:239-580-7800 | Email: info@maximdefense.com



MAXIM
DEFENSE®

www.MAXIMDEFENSE.COM

Specifications subject to change without notice. Actual product may vary from photo. Rev 02242026CH

ATTENTION SDX-RFLX OWNERS:

PLEASE FOLLOW THESE STEPS WHEN REASSEMBLING YOUR RFLX SUPPRESSOR.



After the suppressor has been cleaned / serviced it may be reassembled. In order to reassemble the suppressor, hold the suppressor in the same way as it was held during disassembly.

If the MonoKore was removed, thread the MonoKore into the mount by hand. Remember that the threads between the mount and the MonoKore are left hand threads and turn in the opposite direction as normal threads.




First place the mount of the RFLX suppressor in a vice grip with soft jaws as seen above.



Use a torque wrench set to 30 ft*lbs, torque the MonoKore to the mount.



Once the MonoKore is torqued in place, or in the normal case of not having removed it, slide the suppressor tube over the MonoKore and thread the tube onto the mount by hand.



With a torque wrench and a 1 1/4" socket or crow's foot attachment, torque the suppressor tube to the mount with 40 ft*lbs.

With a variety of operational conditions and the varied pressures of ammunition, your firearm should be cleaned and inspected after each use. To maintain optimal performance, a Preventative Maintenance Program must be established and followed.

Maxim Defense Industries only recommend Lubrication and Cleaning Solvents that are designed for firearms to be used with auto-loading pistols as shipped, and with special adapters, they may be used with pistol caliber carbines if they are chambered in rated calibers for this silencer.

WARNING: Always Unload and CLEAR your firearm before maintenance and cleaning. DO NOT mix parts from one firearm silencer with parts from another firearm silencer. Parts are not interchangeable unless specifically designated as such. DO NOT mix lubricants on the same firearm or firearm silencer. The User is responsible for following all instruction for the safe use of Lubricants and Solvents.

NOTE: The term "CLP", "Cleaning Solvents" and Lubricant" in this manual are used interchangeably and are to be interpreted to mean that CLP, LSA, LAW can be utilized as applicable. The Firearm must be thoroughly cleaned during the change from one lubricant to another using a dry cleaning Solvent (SD). DO NOT mix lubricants on the same firearm.

Always read the warning label on any cleaner or solvent and remember that virtually all solvents are inherently dangerous and potentially toxic. Always use adequate ventilation and both skin and eye protection when using solvents.

Never use a patch to clean the barrel with the suppressor in place, as the patch may become lodged in the baffle system.

For suppressor installation, torque should not be above 40 ft*lbs, but not below 25 ft*lbs (firmly hand tight).

It is recommended that the user periodically ensure that the suppressor is tight. To do so: cease fire, unload and visually and physically inspect the firearm to be clear and safe, then allow the suppressor to cool to ambient temperature and only then try and tighten the suppressor by hand (turning clockwise). The suppressor should be checked to ensure it is tight to the barrel after every magazine.

WARNING: Suppressors are VERY HOT under fire. Never attempt to see if the suppressor is tight soon after it has been fired, as there is nothing that can protect your hand while grabbing a metal object that is as hot as a suppressor can get. It is always safest to allow the suppressors to cool all the way to room temperature to check that it is still torqued in place.



ATTENTION SDX-RFLX OWNERS:

PLEASE FOLLOW THESE STEPS WHEN DISASSEMBLING YOUR RFLX SUPPRESSOR.

Ensure the suppressor is correctly oriented for installation and removal, with only one proper alignment. Prior to usage, it is essential to securely affix the suppressor onto the firearm. Failing to do so may lead to potential damage to both your firearm and the suppressor.

Conduct a visual inspection of the suppressor post-installation to verify that it is perfectly aligned with the centerline of the bore and not tilted in any way. Should you observe any misalignment between the suppressor and the bore, immediately halt the installation process and contact our Customer Service Department.

Utilizing the suppressor when it is improperly mounted could result in irreversible damage to your suppressor, resulting in suboptimal performance and diminished accuracy.

There will be several tools need to disassemble the RFLX suppressor such as a socket wrench/ breaker bar, a 7/8 socket and a 1 1/4 socket.



First secure the RFLX suppressor by placing it in a vice grip as shown above.



Once the suppressor mount is secured in a vice grip, use a driver and a 1 1/4 socket or a wrench, turn the tool feature on the front of the suppressor tube counterclockwise to unthread it.



Remove the suppressor tube and set it aside. The interior of the suppressor tube may be cleaned at this time, as well as the interior of the suppressor core. There are many surfaces of the suppressor core that can / should be cleaned periodically.



Typical build up areas are removed when the tube is removed.



Typical build up areas.

At this point, all of the suppressor components can be fully serviced. It is possible to remove the suppressor core, but in general it is not recommended to do so. Simply scrub and brush deposits away from accessible interior surfaces of the MonoKore.

If you feel the need to remove the suppressor core from the mount, there is a 7/8" socket / wrench tool feature on the front of the MonoKore. The MonoKore is threaded into the mount with left hand threads (reverse from normal right hand threads). The MonoKore is threaded into the mount and torqued at 30 ft*lbs.

When fully cleaned, the interior of the tube will still have visible carbon deposits. It will not be possible to get all of them off. The best way to clean the carbon off of the interior of the tube is to turn the tube around the MonoKore. Unthreading the suppressor tube and removing the tube from the mount and core assembly should remove most of the carbon deposits that need attention.

If it seems abnormally difficult to get apart, contact the Maxim Defense Customer Support Team.

The suppressor tube should always be removed after use once the suppressor has allowed to cool to ambient temperature.

